## **MPU117/1**

## Voltage Measuring Converter (DC/DC)

The voltage converter, MPU 117/1, belongs to the group of measuring converters using the two-way rectification method. The converter converts the input AC voltage to the output DC current or DC voltage signal. The output signal is galvanically isolated from the supply voltage and the input signal.



1		
2		
3	POMOĆNO NAPAJANJE	
4	220V 50Hz	
5		
6	MERNI NAPON	
7	V	
8	+ IZLAZ (mA)	
9	- IZLAZ (mA)	
10		
11	MERNI NAPON	
	MERNI NAPON	
	11 6	

	Power Supply	Input	Output
1	24 VDC	0 – 100 VAC	0 – 1 – 10 mA
2	20 – 60 VDC	0 – 250 VAC	0 – 2 – 20 mA
3	48 VDC	0 – 500 VAC	0 – 1 – 10 V
4	110 VDC	/	/
5	100 – 240 VDC/AC	/	/
6	230 VAC	/	/
7	/	/	/
8	/	/	/
9	/	/	/
0	per request	per request	per request

## **Technial Data**

Electronic rectifier	
100V, 100/√3V, 220V,	
380V, 500V	
50Hz, 60Hz	
<2VA	
1.2Un	
2Un	
>10kΩ	
$700 - 1500\Omega$	
200ms	
0.2%	
0.2%	
0.1%	
0.1% / 10°C	
-10°C…+55°C	
-40°C+70°C	
±20%	
±20%	
4kV, 50Hz, 1min	

MPU 117/1 type is based on the desired combinations from table:

PowerSupply.Input.Output, for example:

MPU 117/1 1.3.2 has a 24VDC power supply, an input voltage in the range from 0 to 500VAC, and the output current is in the range 0-20mA, where the breaking point of the output signal is 2mA;

MPU 117/1 3.2.1 has a 48VDC power supply, input 0-250VAC, and the output current is in the range 0-10mA, where the breaking point of the output signal is 1mA;

MPU 117/1 0.0.0 (or just MPU 117/1) is based on user needs.

www.pupin.rs



"Mihajlo Pupin" Institute 15, Volgina St. Automation and Control Systems 11060 Belgrade, Serbia Tel: +381 11 6771 017 automatika@pupin.rs Fax: +381 11 6782 885 info@pupin.rs







